



SEMI-AUTOMATIC ELECTRIC MACHINES LABORATORY



DL OPENLAB-SA

The DL OPENLAB-SA offers a "first glance" at the vast and complex world of electric machines.

The main characteristic of this laboratory is its "open" structure, where rotor windings, stator windings and brushes are completely exposed to perform didactic experiences such as the analysis of magnetic fluxes and magnetic fields. In this way, the students can learn in detail the internal construction and assembly of different types of electrical machines and carry out practical tests for the acquisition of their operating characteristics.

This modular system operates at low voltages providing a safe hands-on training environment with the addition of the plexiglass protection preventing direct contact with the rotating electrical machines to avoid injury.

The DL OPENLAB-SA includes a software developed in LabVIEW that communicates with the main measuring modules in the system to acquire the electrical and mechanical values.

Ideal for 4 students to work simultaneously.

Vocational and technical schools.

Applicable to courses in: Magnetism and electromagnetism, electromechanics, electric machines, power engineering.



DIDACTIC EXPERIENCE AND APPLICATION

The DL OPENLAB-SA trainer is a hands-on learning platform that provide a comprehensive course on electrical machines. It introduces the basic concepts of electrical machines construction starting from the electromagnetism principles with the analysis of magnetic fields and fluxes, until more advanced experiments with the characterization and the efficiency analysis of rotating machines in different working conditions.

Through this system, it is possible to assemble the most common types of electrical machines found in the industry to carry out the following didactic experiences:

- Study of the magnetic field
- Principles of the electromagnetic induction
- Separately shunt, series and compound excited dc motors
- Separately shunt, series and compound excited dc generators
- DC motor and DC generator with permanent magnet
- Induction motors: three-phase slip ring and squirrel cage, single-phase repulsion and with capacitor
- Dahlander connection
- Synchronous three-phase motor, induction regulator and phase shifter, alternator, universal motor

SET OF ASSEMBLABLE MACHINES

The core of the system is the DL 10280, which includes all the components needed to assemble different types of rotating machines. The set consists of:

- 1. Base plate
- 2. Supports with bearing
- 3. Coupling joints
- 4. Flexible coupling
- 5. Electronic speed transducer
- 6. Assembling screws
- 7. Wrenches
- 8. DC stator
- 9. AC stator
- 10. Rotor with commutator
- 11. Brush holder with 2 brushes
- 12. Squirrel cage rotor
- 13. Slip-Ring rotor
- 14. Brush holder with 6 brushes







DATA ACQUISITION AND PROCESSING SOFTWARE



The **DL OPENLAB_DAS** is a software developed for the acquisition and display the data of the DL OPENLAB_SA laboratory. It is developed in LabVIEW and communicates with the instruments (DL 10282NF and DL 10055NF) via serial port using the Modbus protocol and acquire mechanical data (speed and torque) as well as electrical data (AC and DC, Voltage, current and Power).

periment config	juration Mea	asuring process	Data Grag	h								
Torque	V2 Voltage	easurement points	Torque	Speed	P13 Power	V2 Voltage	12 Current	P23 Power	Power	Cos (phi)	Eff. (%)	
0,577	48,674	0.1	0,024	2976	50,785	49,732	1,345	-9,172	7,478	0,359	17,971	
510		02	0,097	2958	61,122	49,972	1,459	3,060	30,041	0,508	46,806	
Speed	12 Current	0.3	0,194	2934	76,153	48,033	1,696	17,375	59,595	0,663	63,719	
2724	3,742	0.35	0,307	2880	103,746	49,215	2,215	43,484	92,572	0,780	62,875	
P13 Power P23 Power		0.4	0,339	2862	113,271	49,051	2,401	51,109	101,582	0,806	61,797	
170 243	04 377	0.45	0,395	2832	121,880	48,976	2,675	61,567	117,122	0,808	63,845	
110,640	anorr (0.5	0,439	2808	136,928	49,053	2,892	68,177	129,065	0,835	62,926	
Accuracy fine tuning 0,55		0,484	2790	148,797	49,048	3,128	76,713	141,383	0,849	62,695		
		0.6	0,530	2754	162,658	48,857	3,434	86,119	152,822	0,856	61,429	
in	Max	Amazina and	0,577	2724	179,243	48,674	3,742	94,377	164,562	0,867	60,143	
Search limits									Torque versus speed			
,576 0	624							-				



FEATURES

- For each experiment, set number of measurements and accuracy and acquire data.
- 2. Trace the characteristic curves of the elements under study using the acquire data.
- 3. Export data in .xls file for further analysis



ELECTRICAL MACHINES SMART SIMULATOR SOFTWARE

The DL OPENLAB-SA includes the smart simulator DL OPENLAB-SSEM. It is a performant new generations educational course that permits a complete and innovative didactic experience on electric machines in a virtual reality environment.

It has been developed to reproduce the features and behaviours of the real electric machines' laboratory. The didactic experience includes electric machines assembly (rotos, stators, supports, couplers), wiring the machines following the software instructions, the students submit them to different working conditions and make measurements to study its behaviour.







FEATURES:

- VIRTUAL SIMULATION OF ELECTRIC MACHINE LABORATORY: Students can replicate experiments of the real system away from the classroom like a home environment.
- AUTOMATIC VALIDATION OF STUDENTS' TASKS: the software automatically verifies if the student successfully completed each task to allow him/her to go ahead with the next one.
- TRACKING OF STUDENTS' PROGRESS: the teacher can verify the students' progress any time consulting the specific summary in the software or exporting it to a spreadsheet.





LABORATORY COMPOSITION

CODES	DESCRIPTION	QTY		
DL 10280	Set of assembled machines	1		
DL 10280MP	Permanent magnet stator			
DL 10281	Power supply module	1		
DL 10282NF	Electrical measurement module	1		
DL 10055NF	Mechanical power digital measuring unit	1		
DL 2006D	Load cell	1		
DL 10283	Loads and rheostat module	1		
DL 10284	Adapter bracket	1		
DL 10285	Locking and rotatable device	1		
DL 10185	Pole changing unit	1		
DL 10310NF	Parallel board module	1		
DL 10300A	Electromagnetic brake	1		
DL 10116	Star-delta starter	1		
DL 10125	Starting and synchronization unit	1		
DL 2100-3L	Three-level work frame	1		
DL OPENLAB_DAS	Data acquisition and processing software	1		
DL OPENLAB-SSEM	Electric machines smart simulator software	1		



EXPERIMENT LIST

Nr	XPERIMENT MODULES													
		DL 10280	DL 10280MP	DL 10281	DL 10282NF	DL 10055NF DL 2006D	DL 10283	DL 10284	DL 10285	DL 10185	DL 10310NF	DL 10300A	DL 10116	DL 10125
1	Flux produced by the poles	Х		Х	Х									
2	Main magnetic field	Х		Х	Х									
3	Intensity of the magnetic field	Х		Х	Х									
4	Induced voltage	Х		Х	Х									
5	Inter pole effect	Х		Х	Х									
6	No-load magnetic neutral axis	Х		Х	Х									
7	Rotating magnetic field	Х		Х	Х		Х							
8	3-phase squirrel cage motor, 2 poles, 24 VΔ	Х		Х	Х	Х		Х				Х		
9	3-phase squirrel cage motor, 2 poles, 42 VY	Х		Х	Х	Х	Х	Х				Х		
10	3-phase squirrel cage motor, 2 poles, 24 V $\Delta\Delta$	X		Х	Х	X		Х				Х		
11	3-phase squirrel cage motor, 2 poles, 42 VYY	X		X	X	X		Х				X		
12	3-phase squirrel cage motor, 4 poles, 24 VΔ	X		X	X	X		X				X	Х	
13	3-phase squirrel cage motor, 4 poles, 42 VY	X		X	X	X		X				X		
14	3-phase Dahlander motor, $4/2$ poles, $42 V\Delta/YY$	X		X	X	X	v	X		Х		X		
15	Split phase motor	X		X	X	X	X	X				X		
10	Capacitor start and run motor	X		X	X	X	X	X				X		
10	S-phase motor with wound rotor, 2 poles, 42 viii	× ×		×	× ×	~	× ×	× ×	v			~		
10		X		^ V	^ V		^ V	^ V	^ V					
20	3-phase synchronous induction motor 2 poles 24 VA	× ×		× ×	× ×	v	^	× ×	^			Y		Y
20	3-phase synchronous induction motor, 2 poles, 24 VA	X		^ X	^ X	X		^ X				X		X
22	DC motor with senarate excitation	X		X	X	X	x	X				X		~
23	DC motor with sound excitation	X		X	X	X	X	X				X		-
24	DC motor with series excitation	X		X	X	X	X	X				X		
25	DC motor with compound excitation, long shunt	X		X	X	X	X	X				X		
26	DC motor with compound excitation, short shunt	X		X	X	X	X	X				X		
27	Single phase series motor	Х		х	Х	Х		Х				Х		
28	Repulsion motor	Х		Х	Х	Х	Х	Х				Х		
29	Synchronous motor winding resistance	Х		Х	Х									
30	Synchronous motor no-load test	Х		Х	Х		Х							
31	Synchronous motor short-circuit characteristics	Х		Х	Х		Х							
32	Synchronous motor short-circuit test	Х		Х	Х		Х							
33	Synchronous motor Behn - Eschenberg's method	It uses the data from experiments 29, 30, 31							31					
34	ynchronous motor load test X			X X X X										
35	Synchronous motor conventional efficiency			lt us	It uses the data from experiments 29, 30, 32, 33									
36	Parallel connection of the alternator with the mains	Х		Х	Х	Х	Х				Х			
37	Alternator as synchronous motor	Х		Х	Х	Х	Х				Х			
38	DC generator winding resistance	Х		Х	Х	Х								
39	DC generator test of the no-load motor (Swinburne)	Х		Х	Х	Х	Х							
40	DC generator no-load e.m.f.	Х		Х	Х	Х								Х
41	DC generator excitation characteristics	Х		Х	Х	X								X
42	Separate excitation dynamo	Х		X	X	X	X							X
43	Shunt excitation dynamo	X		X	X	X	X							X
44	Series excitation dynamo	X		X	X	X	X							X
45	Compound excitation dynamo	X	¥	X	X	X	X	V				V		Х
46	DC motor with permanent magnet	X	X	X	X	X	X	Х				Х		
4/	DC generator with permanent magnet	X	X	X	X	X	X							







Three-phase squirrel cage motor, 2 poles, 24 V∆

This experiment studies the behavior of the threephase squirrel cage motor in load condition with the stator windings connected in delta.

Three-phase squirrel cage motor, 2 poles, 42 VY

The main objective of this experiment is to study the characteristic curve of a three-phase squirrel cage motor with the stator winding connected in star by performing a direct test using an electromagnetic brake.





Three-phase squirrel cage motor, 2 poles, 24 V $\Delta\Delta$

Applying the same concepts studied up to this point, the students can plot the load characteristics of the three-phase squirrel cage motor connected in double delta.

Three-phase squirrel cage motor, 2 poles, 42 VYY

Flowing the same procedure with the stator winding connected in double star, the student will trace the curves for the absorbed current I, the power factor $\cos\varphi$, the speed n and the efficiency η as a function of the output power P.





Three-phase squirrel cage motor, 4 poles, 24 V Δ

In addition to recording the operation characteristics of the motor, the students will learn how to start the motor using a star-delta starter.



Three-phase squirrel cage motor, 4 poles, 42 VY



In this experiment, the student will learn the load operation of a three-phase motor with 4 poles.

Three-phase squirrel cage motor, 4/2 poles, 42V Δ /YY

In previous experiments, it has been demonstrated that by changing the number of poles it is possible to vary the speed of a squirrel cage motor. The students will learn about two-speed Dahlander motor configuration and its operation.





Split phase motor

The split phase motor, also known as a resistance start motor, has a single cage rotor and its stator has two windings known as main winding and starting winding. The main objective of this experiment is to study the characteristics of the motor with the main winding only, and to draw the curves of current I, efficiency η , torque C, output power P and power factor.



Capacitor start and run motor

3

The objective is to study the characteristics of the motor with permanently connected capacitor. The students will learn how to properly select and connect a capacitor to the auxiliary windings so that the current trough the main winding lags behind the current of auxiliary windings by an angle on 90^o.





Three-phase motor with wound rotor, 2 poles, 42 VYY

The student will record the load characteristics of the motor with a wound rotor and the stator connected in double star.

With the knowledge acquired up to this point, it will be easy to draw the diagram of mechanical characteristic M = f(n) and to observe the behavior of an induction motor with a different type of rotor.

Phase shifter

The objective is to study how the phase between the stator and rotor voltages varies in function of the rotating angle and identify the null phase shift condition using Lissajous' ellipse by setting the oscilloscope to XY mode.





Induction regulator

30

The objective is to study the operation of a threephase voltage regulator. By using a locking and rotating module with a graduated disc, the rotor can be turned by means of the hand-wheel until the load current results null with minimum indication of the voltmeter.

The student will measure the absorbed current at constant load and draw the current and voltage curves as a function of the angular phase shift.





Three-phase synchronous induction motor, 2 poles, 24V $\Delta\!\Delta$

Following the same procedure as in previous experiment, the diagram of the absorbed current I, the power factor $\cos \phi$ and the efficiency η as a function of the output torque *c* will be traced with the stator wired in delta-delta configuration.



This experiment studies how to start and synchronize the induction motor using the starting rheostat and study the load characteristics of the motor at synchronous speed.





DC motor with separate excitation

Now is time to work with DC motors. First application refers to a separately excited DC motor, where the field winding is powered by an external independent source. The DC motor operation characteristics will be studied as a function of the excitation voltage.



DC motor with shunt excitation

<u>%</u>

By performing this experiment, the student will learn how to connect that the armature and field windings in parallel and you compare the behavior with the previous experiment.



DC motor with series excitation

Unlike in the DC shunt motor, the DC series motor has very poor speed regulation. The main objective of the experiment is to draw the characteristics of the output power P, the speed n, and the efficiency η as a function of the absorbed current I.



DC motor with compound excitation, long shunt

By combining the operational characteristic of both the shunt and series excited DC motor we obtain the one of the DC compound excitation motor. The operation of the motor is studied with cumulative and differential excitation.





Study of DC motor with compound excitation, short shunt

This experiment shows why the compound motor responds better to heavy load changes than a shunt motor.

Study of single-phase series motor

Single phase series motor, also known as a universal motor, is a rotating machine similar to a DC motor but designed to operate either from DC or single-phase AC.









Study of repulsion motor

The repulsion motor combines a stator of a singlephase motor with a rotor similar to that of a DC motor. The main benefit of the repulsion motor is that the armature is separated from the line. The main objective of this experiment is to record its operation characteristics.

Measure the windings resistance of the alternator

This experiment calculates the voltage drops across the rotor winding resistance of an induction motor using Ohm's law. The winding resistance value of the alternator is useful to calculate the conventional efficiency.





Short-circuit characteristic of the alternator

The short-circuit test of the synchronous generator provides information about its current capabilities. It is performed by driving the generator at its rated speed while the terminals of the armature winding are shorted.

This characteristic diagram is essential for the application of the indirect testing method of the alternator.

No-load test of the alternator

The main objective of this experiment is to determine the mechanical and iron losses of the alternator and to record its magnetization characteristic using a DC motor as prime mover.







Load test of the alternator

This test compares the behavior of a synchronous generator connected to a variable external load with its no-load operation.

Conventional efficiency of the alternator

The conventional efficiency of a synchronous machine is determined by measuring the losses operating at different power factors, using the results from the previous experiments.





Study the "V" curve of the synchronous motor

The V-curve of a synchronous machine shows its performance in terms of variation of the armature current with the field current when the load and the input voltage of the machine are maintained constant.

The students will trace different V curves for particular resistant torque applied to the motor axis.

Parallel connection of the alternator with the mains

This experiment studies an operation which is frequently performed in a power station. The synchronization of a generator consists of electrically coupling the generator output to another source of electrical energy and operating the generator such that its output adds to the other source.





Measure the windings resistance of the DC generator

This experiment demonstrates how measuring the internal resistance of a DC machine can be used to establish the integrity of the machine windings and internal connections.

Test of the no-load motor (Swinburne)

In order to design rotating DC machines with higher efficiency, it is important to study the losses occurring in them. Swinburne's method consists of operating a dynamo as a DC motor with no load to determine its mechanical and iron losses.

This is done by increasing the armature voltage U while measuring the armature current Ia and the excitation current Ie.



Magnetization characteristic of a DC Generator

This experiment studies the magnetization characteristic of a separately excited DC generator using a three-phase synchronous motor as prime mover.

Study of separate excitation dynamo

The main objective of this experiment is to record of the external and regulation characteristics of a separate excitation generator to determine its conventional efficiency.

This is done by measuring the output voltage U as a function of the load current, with constant excitation current $I_{e.}$











Study of series excitation dynamo

Determining the external characteristic of a DC generator connected in series is to observe how the voltage slightly drops as the load increases. Students will use these results to calculate the conventional efficiency of the dynamo.

Study of shunt excitation dynamo

The previous experiment is replicated with a different configuration of the DC generator. Using the results from the previous experiments, the student will plot the external and regulation characteristic of the generator connected in shunt.





Study of compound excitation dynamo

This experiment follows the same procedure as the previous ones with the generator in compound excitation connection. After performing this last experiment, the students will be able to make comparative analyses between all the different DC generator configurations.